













Add the next two metal rods until the top rod has been pushed all the way till the end of the sleeve







