

- 1. Hardware contents plus print 2 poles with silver hooks
- Collapsible Frame
- Printed Poster with eyelets in each comer



2. Expand the frame in an upright position



3. Ensure the back leg appears as in photo



4. Insert both poles into top of base as shown in photo. Ensure hook at the top of the pole is facing to the front.







**5.** Place printed banner eyelet over the hook. As shown in the photos above.



**6.** For the bottom corners of the printed banner place the eyelet under the hook as it appears in the photo above.



