



POP-the-Wall Assembly Guide


IMPORTANT: Product Fragile - Handle with Care.




1. Lay the frame flat on the ground, make sure the 2 blue blocks are on top and facing you. Ensure the ground is completely flat and free of debris, as a non-flat surface will cause the frame to misalign and the panels will not hang straight.




2. Grab two of the poles and gently pull the frame upward.




3. Before the frame is fully opened, push both sides inward and make sure the four magnetic poles are locked together properly.



4. A fully opened and stablised frame.




5. Install the magnetic bars from the top to bottom. Make sure the top edge of the bar aligns with the bottom row of the magnetic dots.




6. Install all 16 magnetic bars, 12 at the front, 6 at the back. The two middle poles at the back do not require magnetic bars.




7. Install the graphic panels, align the magnetic dot on the top right with the top left dot of the frame joint. Setup the panel from the top first then press evenly from top to bottom on the magnetic strip.



8. When installing the graphic panels, start from the middle to avoid any alignment problems. When attaching panels to frame ensure that each magnetic strip on the printed panels is pressed firmly onto the magnetic strip on the frame.




Install all 5 graphic panels.



10. Slide the lamp base gently into the lamp slot.



11. Slide the 2 spot lights on the top cross joint of the frame.



12. Complete.

IMPORTANT: Ensure all panels are rolled with the image side facing out. If rolled with the image side in this may damage the lamination.



Skirt Graphics Assembly Guide | Skirt Graphics Disassembly Guide

IMPORTANT: Ensure all panels are rolled with the image side facing out. If rolled with the image side in this may damage the lamination.



 To install the carry case skirt, first, wrap the skirt around the carry case.



2. Holding the graphic panel stuck to the case tight to the case peel the paper from double-sided velcro on panel and adhere to case. Ensure strip adheres strongly by pushing strip firmly and evenly onto case.




Disassembly Guide


1. When taking the skirt graphic off the case peel down slowly from the top of with care to ensure the Velcro strip stays stuck to the case.

POP-the-Wall Disassembly Guide

IMPORTANT: Ensure all panels are rolled with the image side facing out. If rolled with the image side in this may damage the lamination.



1. Gently remove all panels by pulling up from bottom to top Then gently remove the two spot lights.




sheet provided, all panels should have the graphic facing down.




 Grab the bottom panel and gently roll all five panels together.



4. Do not roll the panels too tight to avoid any damages on the surface. Ensure all panels are rolled with the image side facing out.




5. Take off all the magnetic strips.



6. Pull the frame gently to disconnect the magnetic joints.



7. Slowly push down the frame.



8. Complete.